

Measurement list

	Unisex chef trousers Christian	C44	C46	C48	C50	C52	C54	C56	C58	C60
A.	Waist along top edge	77	81	85	87	93	99	103	107	111
B.	Seat/hip at fly end (straight mmt)	96	100	103	107	111	113	117	121	125
C.	Thigh at crotch point	61	63	65	67	69	71	73	75	77
D.	Front rise below waistband	22	22,5	23	23,5	24	24,5	25	25,5	26
E.	Back rise below waistband	31,5	32	32,5	33	33,5	34	34,5	35	35,5
F.	Knee at 1/2 of inseam length	42,5	43	43,5	44	44,5	45	45,5	46	46,5
G.	Bottom leg opening	35,5	36	36,5	37	37,5	38	38,5	39	39,5
H.	Inseam	80	81	82	83	84	85	86	87	88
I.	WB height	4	4	4	4	4	4	4	4	4
J.	Fly zipper length	12,5	13	13,5	14	14,5	15	15,5	16	16,5
K.	Fly length	13	13,5	14	14,5	15	15,5	16	16,5	17
L.	Side pocket at side seam	15,5	16	16,5	17	17,5	18	18,5	19	19,5
M.	Back pocket opening	16	16	16	16	16	16	16	16	16

