

MONTERINGSANVISNING

ASSEMBLY INSTRUCTIONS

STAAL BOKHYLLA


Art. Nr 18076-201



Assembly instructions | Monteringsanvisning



Assembly Instruction(18076 Staal Bookcase)



1 1pc	2 1pc	3 3pcs
4 3pcs	5 4pcs	6 3pcs
7 2pcs	8 3pcs	A 28pcs
C 1pc	D 2pcs	E 2pcs
		B 36pcs
		F Ø12X5 6pcs

1 Ax2

2 Ax10

3 Ax12
Fx 6

4 Bx36
Dx2
Ex2

MONTERINGSANVISNING

ASSEMBLY INSTRUCTIONS

STAAL BOKHYLLA


Art. Nr 18076-208



Assembly instructions | Monteringsanvisning



Assembly Instruction(18076 Staal Bookcase)



1 1pc	2 1pc	3 3pcs
4 3pcs	5 4pcs	6 3pcs
7 2pcs	8 3pcs	A 28pcs
C 1pc	D 2pcs	E 2pcs
		B 36pcs
		F Ø12X5 6pcs

1 Ax2

2 Ax10

3 Ax12
Fx 6

4 Bx36
Dx2
Ex2

MONTERINGSANVISNING

ASSEMBLY INSTRUCTIONS

STAAL BOKHYLLA


Art. Nr 18076-205



Assembly instructions | Monteringsanvisning



Assembly Instruction(18076 Staal Bookcase)



1 1pc	2 1pc	3 3pcs
4 3pcs	5 4pcs	6 3pcs
7 2pcs	8 3pcs	A 28pcs
C 1pc	D 2pcs	E 2pcs
		B 36pcs
		F Ø12X5 6pcs

1 Ax2

2 Ax10

3 Ax12
Fx 6

4 Bx36
Dx2
Ex2